

4F-1, 236, Fu-Te 2nd Rd., His Chih,

Taipei Hsien, 221, Taiwan

TEL:886-2-6616-6692 · 2694-6687

FAX:886-2-2694-6875 · 2694-5097

Y Rollers Changing Process Spirit

Version: 1.0 May 20, 2014





Revision History:

Version	Date	Page	CONTENTS
1.0	May, 20 2014		First release




1. Dismount 2 screws of top cover(M4 *8)







2. Lift the top cover •




3. Please turn the safety lock switch to LOCK status according to the direction shown on the sticker (see picture) to avoid the collapsing of top cover.







4. Changing the Y rollers. Remove the following screws to completely remove the Y rollers.



5. Unscrew the following screws to remove the A roller.

